



## Twisted Chef Oven Liner

### Important Use and Care Instructions

*Please read these instructions carefully prior to using the oven liner, as improper use may cause permanent damage to your oven.*

CAUTION: Failure to use the oven liner as directed could damage your oven.

- **DO NOT** use directly on oven element or open flame.
- **DO NOT** use self-clean mode with your oven liner in oven – remove it first.
- **DO NOT** use above 500°F (260°C)
- **DO NOT** (gas ovens only) cover or block any holes or vents inside the oven – covering holes could create unsafe carbon monoxide levels.

Please note: oven liners are safe to use in convection ovens.

For optimum circulation, please ensure that you trim the oven liner so that there is between 1 and 2 inches between all sides of the oven liner and the walls (and door) of the oven. You may place baking dishes and pans directly on the oven liner's surface.

**Twisted Chef Oven Liners** are dishwasher safe or can be washed in warm soapy water. Wipe dry with a soft cloth. To preserve the non-stick qualities, do not fold the oven liner or use abrasive cleaners or sharp objects. After use some discoloration may occur but will not affect its performance.

### PLACEMENT FOR ELECTRIC OVENS WHERE THE ELEMENT IS VISIBLE:

Place oven liner directly under the visible element. The oven liner **should not** touch the walls or door of the oven.

### PLACEMENT FOR ELECTRIC OVENS WITH NO VISIBLE ELEMENT:

Place oven liner on the bottom wire rack of the oven. **DO NOT** place on the bottom of the oven. You may place baking dishes and pans directly on the liner's surface. If the oven liner is larger than the oven rack, the oven liner should be cut to fit the dimensions of the oven rack. The oven liner **should not** touch the walls or door of the oven.

### PLACEMENT FOR GAS OVENS:

Place oven liner on the bottom wire rack of the oven. **DO NOT** place on the bottom of the oven. You may place baking dishes and pans directly on the liner's surface. If the oven liner is larger than the oven rack, the oven liner should be cut to fit the dimensions of the oven rack. The oven liner should not touch the walls or door of the oven. **DO NOT** cover or block any holes or vents inside the oven – covering holes could create unsafe carbon monoxide levels.

**FOR MORE INFORMATION AND TO JOIN OUR EXCLUSIVE VIP MEMBERS CLUB, PLEASE VISIT OUR WEBSITE AT:**

**[www.twisted-chef.com](http://www.twisted-chef.com)**